

## WORKSHEET FOR DETERMINING SAND EQUIVALENT AASHTO T 176

Project: \_\_\_\_\_ Source: \_\_\_\_\_

Where sampled: \_\_\_\_\_ Quantity represented: \_\_\_\_\_

Sample of: \_\_\_\_\_ Lot no.: \_\_\_\_\_ Sample No.: \_\_\_\_\_

Sampled by: \_\_\_\_\_ Date: \_\_\_\_\_ Tested by: \_\_\_\_\_ Date: \_\_\_\_\_

The following method was used to prepare the sample: ☐ Air dry ☐ Pre-wet ☐ Oven dried

**NOTE:** In each cylinder, place about 85 mL by volume of quartered material passing the 4.75-mm sieve.

Soaking Time (10 minutes ± 1 minute)				Sedimentation Period ( 20 minutes ± 15 seconds)			
Determination	1	2	3	Determination	1	2	3
Cylinder no.				Cylinder no.			
Starting time				Starting time			
Finish time				Finish time			
<b>CALCULATIONS: SE = <math>\frac{\text{Sand Reading}}{\text{Clay Reading}} * 100</math></b>				Sand reading			
				Clay reading			
				Sand equivalent (SE) values <sup>1</sup>			

Sand Equivalent (mean)<sup>2</sup> =

**Remarks:** \_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

<sup>1</sup> Mathematically round calculated value to nearest 0.1. After rounding to nearest 0.1, then round the result up to a whole number and record.

<sup>2</sup> Mathematically round calculated SE mean to nearest 0.1. After rounding to nearest 0.1, then round the result up to a whole number and record that as the SE value of the sample.